



LPG PRESSURE REGULATOR model AT07 MAINTENANCE KIT

ATTENTION: maintenance shall be done only by qualified personnel and in accordance to requirements of ECE 67R. After reinstallation, verify any possible gas leakage presence using gas detectors.

At least once in a year, or every 20.000 km, it is suggested to maintain the filter unit with proper original kit RGAT2070, and to drain the oil deposited into the reducer removing the drain screw. The latter operation shall be done when the engine temperature is around 50°C.

A complete maintenance is recommended every 50.000 km or 3 years, or if the car remained unused for a long time (1 year), by using maintenance kit RGAT2060A.

Make a complete revision more frequently in case of dirt or contaminants presence in the water or gas circuit.

COMPLETE KIT RGAT2060A

FILTER KIT RGAT2070

Fixing torque
 $4 \pm 1 \text{ Nm}$

Fixing torque
 $4 \pm 0.2 \text{ Nm}$

Fixing torque
 $5 \pm 1 \text{ Nm}$

Use a clamp during unscrewing and screwing

Fix screw in cross sequence until reaching plane and then complete till indicated torque

Fixing torque
 $4 \pm 0.2 \text{ Nm}$